Radioguide RADIOGUIDE RG-07 USER MANUAL

THE RG-07 BROADCAST RADIO COMMUNICATION DEVICE IS USED TO ORGANIZE ONE-WAY, WIRELESS SPEECH TRANSMISSION ACROSS SHORT DISTANCES.

To create a group, you will need to "link" several receivers to the transmitter.

LINKING PROCEDURE:

1 Power on the transmitter to which the receivers will be linked.


2 Hold down the top button on the transmitter.

3 On the receiver, press and release both buttons simultaneously. The receiver should receive a built-in command from the transmitter and move onto the appropriate channel. Information about the channel (its frequency number and transmitter code) are stored in the receiver's nonvolatile memory.

TO CONDUCT A TOUR:

- Insert the headset plug into the jack at the top of the transmitter.
- 2 Power on the **transmitter** by pressing the top button.

- Insert the headphone plug (up to the rubber stopper) into the jack at the top of the **receiver**.
- The **receivers** will power on after any button is pressed or within 40 seconds after the **transmitter** is powered on.



- 5 To adjust the volume, use the buttons on the left-hand side of the **receiver**. The top and bottom buttons increase and decrease the volume, respectively.
- 6 After the tour, turn off the transmitter by pressing the lower button. The LED light on the transmitter should turn off.
 - 0
- 7 The receivers turn off automatically after not receiving a transmitter signal for more than 10 minutes.



- 10 Kolomenskaya St. Office 5St. Petersburg 191040
- +7 (812) 575-58-24

- www.radioguide.net
- work@radio-guide.ru
- radio_guide